



Sairam Vedam Director, QLabs

BrighTest


Labs

- ✓ BrighTest is an in-house tool .
- ✓ Built on top of Selenium and uses Java
- ✓ API based approach
- ✓ Easily customizable to suite specific project requirements
- ✓ Ability to store reports in our own format for future use.
- ✓ Easy to install.
- √ Easily redefined parameters
- ✓ Customized Alerts and Reports.
- √Weekly and Nightly build integrations (ANT)
- ✓ Applicable for web based applications, products as well as Social Platforms testing.
- ✓ Pilot usage on for couple of happy customer engagements.
- ✓ Extensively used to test Pramati's Enterprise 2.0 product **Qontext**.



BrighTest Modules






BrighTest-Runner



BrighTest-Runner is Frame work to Run Test Cases.


It take Excel Test file/files as in put and start real time web testing.



How does BrighTest-Runner work?



- √ Fetches test cases from the source (.xls, test link, google spread sheet etc)
- ✓ Converts to brightest server command format
- ✓ Sends to the brightest server and gets the response from the server
- ✓ Sends the information to the BrighTest reporter



BrighTest-Server




- √ This module provides a bridge between browser and BrighTest-Runner.
- ✓It takes commands from BrighTest-Runner and converts them into browser requests.
- ✓It collects response for each command (Auto Step) and sends it back to BrighTest-Runner

to the two layers belowed	the Tester Test ranser v0.01 date 1 [2008] Micrilla Fischer	(C	E191
		therete and the second	
companies III and realise	Transportation Control of the Contro	manufacture - manufacture of street (street and street	
BrighTest	BrighTest Automated Web Testing Slow Moder [] Tools Volum Exal [Bross Log] 0e2-93d741e1	Last Four Test Communds: ISE enterthream()(th (2))reput) ISESTATION (2)([Imput) type()(-th(2))reput, computer) ISE ementhreasen()(th (4))divide/input)	
OCIAL TWIST	SocialTwist I		Login
	Password		
	Conjunt Personnel Toller (1997) Fronget Personnel Toller (1997)	7 e-mail and	
	Copyright & 2004, Premain	The throughput Thems of use-Phoney-Policy	

BrighTest-Recorder




BrighTest-Recorder is implemented as a Firefox extension, and allows to record, edit, and debug tests in Qlabs format.



BrighTest-Server



BrighTest-Server automatically launches and kills browsers, and acts as a HTTP proxy for web requests from them. BrighTest-Server is great for testing complex AJAX-based web user interfaces under a Continuous Integration system.






BrighTest - Monitor



This module contains the following submodules:

- Load Monitor: The Load Monitor generates load to Web application server and collects Load and stress related data.
- Server Monitor: This monitors the server performance. It collects server related data like memory, garbage collector, Class Loading, Garbage Collector, CPU usage, CPU Time etc.


Real time monitoring. sent to the



Storing report



BrighTest module for report handling -BrighTest-Reporter







Feature	BrighTes t	QTP	Selenium
Cross platform support	Yes	No	Yes
IE support	Yes	Yes	Yes
Firefox support	Yes	Yes	Yes
Safari support	Yes	No	Yes
Opera support	Yes	No	Yes
Concurrent tests support	Yes	No	Yes
System resource usage	Less	More	Less
TestLink Support	Yes	No	No
ODF support	Yes	No	No
Auto Bug logging Support	Yes	No	No
Web Performance Monitoring Support	Yes	No	No
Multiple report format support	Yes	No	No
Sever Monitoring Support	Yes	No	No
UI map support	Yes	Yes	No
Remote Testing support	Yes	No	Yes
Grid Testing Support	Yes	No	Yes






Feature	BrighTest	QTP	Seleniu m
Writing test cases	No Programming Skill Required	Needs VB Scripting	At least one Programmin g Language/ Scripting
External Test Management Tool support	Yes	No	No
Nightly build support	Yes	No	No
Adding new Custom commands	Easy	difficult	Easy
External Bug tracker system support	Yes	No	No
Support many default functions for web Application automation testing	Yes	Less	Yes

Summary





BrighTest – Success Stories



BrighTest has helped us automate and test following Products and Applications ...













Thank you!

sairamv@Pramati.com

